

### **Generation 3.0** Fork Replacement 3/1/2019

**Central Repair-Lime Technical Institute** 



List

**1.T-handle Wrench - Torx** T25

**2 .T-handle Wrench - Torx** T30

3.Torque Wrench


4.V3 Castle Nut Tool

5.8mm&14mm Wrench



T25





### 3.0 Fork Disassembly SOP

**Technical Guideline** 

Video Link





Tools T25 Part


CAUTION

STEP 1

Remove the 3 screws on the brake wire cover with a T25 wrench

Remove the brake wire cover

STEP 2





Tools 8mm&14mm wrench

Part

**CAUTION** 

STEP 3

Loosen the screws with 8mm and 14mm open-end wrenches

STEP 4

Remove the screw






Tools

CAUTION

STEP 5
Remove the spring from the brake line

Cut off the band

STEP 6





Tools

Part

**CAUTION** 

STEP 7

Remove the brake wire housing sleeve

STEP 8

Cut the band off





Part

**CAUTION** 

STEP 9

Pull the brake cable out of the fender

**STEP 10** 

Use the T30 to loosen the 3 screws on the tube



Part

**CAUTION** 

STEP 11

Remove the screws that hold the tube with the T30

STEP 12

Pull out the tube



Tools Part

**CAUTION** 

**STEP 13** 

Pull the tube out and level it

**STEP 14** 

Pull the brake wire out of the fork



Tools

v3 castle nut tool torque wrench

Part


**CAUTION** 

STEP 15

Use v3 castle nut tool unlock the castle nut

**STEP 16** 

Rotate counterclockwise to loosen the nut



Part

CAUTION

STEP 17

Remove castle nut

STEP 18

Remove washer



Part

CAUTION

STEP 19

Unlock second castle nut

STEP 20

Remove castle nut



Part

CAUTION

STEP 21

Remove washer

STEP 22

Remove spring washer



Part

**CAUTION** 

STEP 23

Take out the small bushing

**STEP 24** 

Take out the fork spacer




Tools Part

**CAUTION** 

**STEP 25** Remove the washer **STEP 26** 

Take out the large bushing



Part

CAUTION

STEP 27

Take out front fork from inclined tube

STEP 28

Remove the bearing from the front fork

# 3.0 Fork Assembly SOP

**Technical Guideline** 

Video Link





Part

#### **CAUTION**

Fork has derection, make sure this side face forward



\*\*\*CAUTION\*\*\*

front fork



Part

CAUTION

STEP 3
Install the smaller bushing

Install washer

STEP 4





Part

CAUTION

Pay attention to the screw hole direction.

STEP 5
The spacer has a screw hole and the front side is mounted to the front fork\*\*\*CAUTION\*\*\*

STEP 6

Load the larger bushing



Part

CAUTION


STEP 7

Install the spring washer

STEP 8

Install washer





Tools

3 castle nut tool torque wrench

Part

**CAUTION** 

STEP 9

Install 1st castle nut

**STEP 10** 

Lock the nut clockwise with the tool



Tools

**Part** 

**CAUTION** 

STEP 11

Install washer

STEP 12

Install 2nd castle nut



Tools

Part

**CAUTION** 

STEP 13

Lock the nut clockwise with the tool

**STEP 14** 

Insert the brake wire into the front fork



Tools

Part

CAUTION


STEP 15

Attach the tube to the fork

STEP 16

Lock the screws of the fixed fork with T30





Part


**CAUTION** 


#### STEP 17

Lock the 3 screws on the pinch tube with T30

**STEP 18** 

Insert the brake wire into the fender hole





Tools

Part

**CAUTION** 

STEP 19

Fix the brake wire housing to the brake wire

STEP 20
Insert the brake cable he

Insert the brake cable housing into the fixing slot





Part

**CAUTION** 

**STEP 21** 

Attach the spring to the brake line

**STEP 22** 

Put the brake wire into the brake connection piece



Part

**CAUTION** 

**STEP 23** 

The brake cable ends through the brake link

**STEP 24** 

Lock two nuts





Part

CAUTION

STEP 25

Fix the brake line with a strap

STEP 26

Cut off the end of the strap



Tools
T25
Part

CAUTION

STEP 27

Install the brake wire cover

STEP 28

Lock the 3 screws on the fixed brake wire cover

with a T25 wrench

## Remember to Quality Check & Test Ride.

Wrench On!