


lime

Generation 3.0 Step Brake Replacement 3/1st/2019 Central Repair-Lime Technical Institute





Tools



3.0 Rear Fender Disassmebly **SOP**

Technical Guideline

Video Link

1. Remove the Screws

1min





Tools

-T20 Torx Wrench -T25 Torx Wrench

Part (none)

CAUTION

STEP 1

Remove the 2 screws with a T25 wrench.

STEP 2

Remove the 4 screws of the cover with a T20 wrench.

2. Remove the Motor Cable Cover







-T20 Torx Wrench Part (none) CAUTION

Tools

STEP 3

Remove the 4 screws of the motor cable cover with a T20 wrench.

STEP 4

Push the motor cable cover back and out.

3. Loosen the Rear Wheel





Tools -Spiral socket -Torque wrench

Part (none)

CAUTION

STEP 5


Use the spiral socket tool to remove the left side nut of the rear wheel.

STEP 6

Use the spiral socket tool to remove the right side nut of the rear wheel.

30s

4. Release the Step Brake



Remove the 2 screws with a T25 wrench.

Disconnect the brake light connector.

30s

5. Remove the Step Brake and Fender **30s** Tools (none) Part (none) CAUTION STEP 9 Pull the rear wheel backwards to remove the rear fender.

3.0 Rear Fender Assmebly SOP

Technical Guideline

Video Link

1. Replace the New Step Brake

30s





Tools

-T25 Torx Wrench

Part

-Working Rear Fender/Step Brake

CAUTION

STEP 1


Pull the rear wheel backwards to fit in the rear fender.

STEP 2

Tighten the 2 screws with a T25 wrench.

2. Assemble the Rear Wheel






wheel light cable into the frame slot.

nuts in sequence **CAUTION**

3. Tighten the Rear Wheel





Tools -Spiral socket -Torque wrench

Part (none)

CAUTION

STEP 5 Use the spiral socket tool to tighten the left side screw of the rear wheel. STEP 6 Use the spiral socket tool to tighten the right side screw of the rear wheel. **30s**

4. Replace the Motor Cable Cover







Tools -T20 Torx Wrench Part (none) CAUTION

STEP 7


Put the rubber sleeve on the left and right nuts.

STEP 8

Push the wire protection case forward and tighten the 3 screws with a T20 wrench.

5. Replace the Bottom Cover

1min






Tools -T20 Torx Wrench Part (none) CAUTION

STEP 9

Connect the brake light cable.

STEP 10

Tighten the 4 screws of the cover with a T20 wrench.



Remember to quality check & test ride.

Wrench On!