

# Generation 3.0 Front Wheel Replacement 3/1/2019 Central Repair-Lime Technical Institute





## **Tools**

List

**1.T-handle Wrench - Torx** T25

2. Torque Wrench

3.Spiral Socket Tool

4.8mm&14mm Wrench



Torx Wrench
T25



Spiral Socket tool




8mm & 14mm wrench

## 3.0 Front Wheel Disassembly SOP

**Technical Guideline** 

Video Link





Tools 8mm &14mm wrench

Part (none)

CAUTION (none)

### STEP 1

Loosen the brake cable assembly with 8mm and 14mm open-end wrenches.

STEP 2

Remove the nuts.





Tools (none)

Part (none)

CAUTION (none)


STEP 3

Remove the spring from the brake cable.

STEP 4

Pull the brake cable from the brake cable stop.

1min





Tools
Spriral socket
Torque wrench


Part (none)

CAUTION (none)

STEP 5
Remove the brake cable stop sleeve.

Use spiral socket to remove the spiral nuts on the left and right sides.

STEP 6



Tools (none)

Part (none)

CAUTION (none)

#### STEP 7

Keep the limit washer, spring washer, and spiral nut together.

STEP 8

Remove the front wheel.



Tools

(none)

Part

(none)

**CAUTION** 

(none)

STEP 9

Remove the brake drum.

## 3.0 Front Wheel Assembly SOP

**Technical Guideline** 

Video Link



Tools (none)

Part
Front wheel
Drum brake

CAUTION (none)

#### STEP 1

Place the drum brake on the new front wheel.





Tools (none)

Part

limit washer spring washer spiral nut

**CAUTION** 

Make sure the drum brake is on the same side as the brake cable.

STEP 2

Place the front wheel on the front fork.

STEP 3

Gather the limit washer, spring washer, spiral nut.





Tools
Spiral socket
Torque wrench

**Part** 

limit washer spring washer spiral nut


CAUTION (none)

STEP 4

Install the limit washer, spring washer, and spiral nut on the left and right sides of the wheel.

STEP 5

Use spiral socket tool to tighten the spiral nuts on the left and right side.





Tools (none)

Part brake cable stop sleve

CAUTION (none)

#### STEP 6

Install the brake cable stop sleve on to the brake wire.

STEP 7

Insert the brake cable into the brake cable stop.





Tools (none)

**Part** Spring


CAUTION (none)

STEP 8

Slide the spring on to the brake cable.

STEP 9

Put the brake cable into the brake arm.



F 8

Tools 8mm &14mm wrench

Part 8mm &14mm nuts

CAUTION

(none)

## STEP 10

Tighten the 14mm and 8mm nut on the brake assembly.

## Remember to quality check & test ride.

Wrench On!